## Hull – Topsides & Bottom Maintenance

- Prep bottom (e.g., tape, sand as needed, etc.).
- Mix paint
- Roll on VC 17 paint.
- VC 17M Extra has been discontinued. VC 17M (copper only, no irgarol) is a compatible substitute.



